Circuits Lab 4

Theo Thompson and Dan Kearney

3.3.13

Experiment 1

Our first experiment compared transistors on the same MAT14 transistor array. For each npn transistor, we tied the collector to the $+5\mathrm{V}$ power rail and grounded the emitter. We swept the base voltage from .25V to .65V to characterize the transistor. One way of measuring how well matched transistors are is to measure β and I_s . To do this, we calculated the collector current using KCL:

$$I_e = Ib + I_c$$

We then calculated β :

$$\beta = \frac{I_b}{I_c}$$

To calculate I_s , we used the following relationship:

$$I_c = I_s e^{\frac{V_{be}}{U_t}}$$

Where V_{be} is the base-emitter voltage that we sourced with the SMU. The results of our calculation are summarized in the table below.

β	I_s		
875.52	$2.01*10^{-13}$		
875.64	$2.07 * 10^{-13}$	STD beta: 1	1.18
877.97	$2.10*10^{-13}$		
875.66	$2.07 * 10^{-13}$		
STD Is: 3 77/10c-15			

Beta

Figure 1: